

## INSTALLATION OF VENTILATION FITTINGS 415

Pre-drill with a 3 mm drill (approx. 10 mm deep) for the screw in the window frame and with a 5 mm drill for the guide pin in the hook in the frame. In height, the hook should be about 20 mm lower than the screw in the window frame. We usually put the fittings at the height of the lower window lock, but that's a matter of taste.

